





Problem: The audio output from the 1500NIT display is low:

Solution: There are two volume controls, the first being through Windows Control Panel. Adjust as required:



And the second being on the side of the display:



1. Speaker volume up
2. Speaker volume down